

Carrera®

RC

#370501034X Neon Storm

#370501039 Glow Storm

GB USA Assembly and operating instructions

GR Οδηγίες συναρμολόγησης και λειτουργίας · **RC** 安装和使用说明 · **ROK** 조립과 작동 방법

ENGLISH

GB USA Dear customer

Congratulations! You bought a Carrera RC-helicopter which has been manufactured according to today's state-of-the-art technology. As it is our constant endeavour to develop and improve our products, we reserve the right to make modifications, either of a technical nature or with respect to features, materials, and design, at any time, and without prior notice. For this reason, no claims will be accepted for any slight deviations in your product from the data and illustrations contained in these instructions. These operating and assembly instructions are an integral part of the product. Non-observance of these operating instructions and the safety instructions they contain will render the guarantee null and void. These instructions are to be kept for future reference and in the event that the product is passed on to a third party.

For the latest version of these operating instructions and information on replacement and spare parts available, please visit carrera-rc.com in the service area.

WARNING! Before you first fly the model, find out whether there is a legal requirement to insure model aeroplanes such as this in your country.

Guarantee conditions

Carrera products are technically advanced products (NO TOYS) which should be handled with care. It is important to follow the directions given in the operating instructions. All components have been subjected to careful inspection (technical modifications and alterations to the model for the purpose of product improvement are reserved).

Should any faults nevertheless occur, guarantee is assumed within the scope of the following conditions:

In accordance with the following provisions, Carrera Toys GmbH (hereinafter referred to as "manufacturer") warrants to the endconsumer (hereinafter referred to as "customer") that the Carrera RC-model-helicopter (hereinafter referred to as "product") delivered to the customer shall be free from defects in material or workmanship for two years from the date of purchase (guarantee period). Such defects will, at the manufacturer's option, either be repaired by the manufacturer or fixed by delivering new or refurbished parts free of charge. The warranty does not cover failure due to normal wear and tear, (e.g. to batteries, rotor blades, cabin covering, gear wheels etc.), or damage as a result of improper handling/misuse or unauthorised interference. Any other customer's claims asserted against the manufacturer, especially action for damages, shall be excluded. The contractual and statutory rights of the customer against the seller (supplementary performance, rescission of the contract, abatement, compensation) which exist with the product not having been free from defects at the time of the passing of risk, shall remain unaffected by this warranty.

Claims from this special warranty shall only be valid if:

- the defect reported has not arisen by damage caused by unintended use or misuse as specified in the instruction manual,
- the failure of the product is not due to normal wear and tear
- the product does not show any signs resulting from repairs or other interferences carried out by workshops not having been authorised by the manufacturer,
- the product has only been operated with accessories authorised by the manufacturer and
- the product is sent in together with the original proof of purchase (invoice / receipt) and the completely filled in warranty card which has not been altered in any way.

Guarantee cards cannot be replaced.

Note for EU countries: Reference is hereby made to the seller's statutory guarantee obligation, to the extent that this guarantee obligation is not restricted by the product guarantee.

Notes for AUSTRALIA: Our goods come with guarantees that cannot be excluded under the ACL. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Declaration of conformity

Carrera Toys GmbH hereby declares that this model including the controller conforms with the fundamental requirements of the following EC directives: EC Directives 2009/48 and the other relevant regulations of Directive 2014/53/EU (RED). The original declaration of conformity can be requested from carrera-rc.com.



Maximum radio-frequency power transmitted <10 dBm · Frequency range: 2400 – 2483.5 MHz

Warning!



WARNING! This toy contains small parts which can be swallowed and is therefore not suitable for children under 3 years of age.

WARNING! danger of pinching during operation! Remove all packaging materials and wire fastenings before handing the toy over to the child. For information and to answer any questions, please read packaging, address and instructions in a safe place for future reference. Keep the instructions for use for later reference. Note for adult supervisors: Check if the toy is assembled as instructed. The assembly shall be performed under the supervision of an adult.

WARNING! Not suitable for children under 12 years old!

This product is not intended for use by children without supervision of a parent. Flying the helicopter requires skill and children must be trained under the direct supervision of an adult. **Before first use: Read the user's information together with your child.** Inappropriate use may result in severe injuries and/or damage to property. It has to be operated with care and caution and requires both mechanical and mental skills. The operating instructions contain notes on safety and technical regulations as well as information on maintaining and operating the product. It is indispensable to read these instructions thoroughly before the first usage. Only this helps to avoid accidents with injuries and damage. Hands, hair and loose clothing, including other objects such as pens and screwdrivers must be kept away from the propeller (rotor). Do not touch the rotating rotor. Especially take care that your hands DO NOT get close to the rotor blades!

CAUTION: For use only outdoors – not to be used indoors. Risk of eye injuries. Do not fly near your face to avoid injuries. Start and fly only when the area is appropriate for the intended use (free area, no obstacles) and only within direct visual contact. Only operate under good visibility and calm weather conditions. As user of this product you are solely responsible for handling it safely in order to ensure that neither you nor other persons or their property suffer damages or are endangered.

- Never use your model with weak remote control batteries.
- Avoid busy areas. Always make sure that there is enough space.
- Do not use your model on an open street or in public areas in order not to endanger or hurt anyone.
- **CAUTION: Do not start up and fly when persons, animals or any obstructions are within the flying range of the helicopter.**
- Start and fly strictly forbidden near high voltage poles, railway tracks, roads, swimming pools or open water.
- Only operate under good visibility and calm weather conditions.
- Exactly observe the instructions and warnings for this product and for any possible additional equipment (battery charger, rechargeable batteries etc.) being used by you.
- **Should the helicopter come into contact with any living thing or solid object, immediately return the gas control to zero, in other words the left-hand joystick must be at the stop at the bottom of the slide!**
- Avoid any moisture as this might do damage to the electronics.
- There is a risk to suffer severe injury or even death if you put parts of your model into your mouth or lick them.
- Do not change or modify anything on the helicopter.

If you do not agree to these terms please immediately return the complete helicopter model in new and unused condition to the retailer.

Important information concerning Lithium Polymer rechargeable batteries

Lithium-Polymer (LiPo) rechargeable batteries are significantly more sensitive than traditional alkaline or NiMH-rechargeable batteries which are normally used with radio control units. Therefore the instructions and warnings have to be observed in detail. In case of improper use of LiPo rechargeable batteries there is a danger of fire. Always follow the manufacturers' instructions if you dispose of LiPo rechargeable batteries.

Regulations on disposal for waste electrical and electronic equipment (WEEE)



This symbol, showing refuse bins with a cross through them, denotes that empty batteries, rechargeable batteries, button cells, rechargeable battery packs, equipment batteries, disused electrical equipment, etc. should not be disposed of in domestic refuse, as they are harmful to the environment and health. Please help to preserve environment and health and talk to your children about the correct disposal of used batteries and disused electrical equipment. Batteries and disused electrical equipment should be handed in to

RC Power
carrera-rc.com

Made in China · Fabriqué en Chine

Digital version



- 전원 스위치에서 컨트롤러를 켜십시오. 접속을 시도하는 중에 컨트롤러에서 신호음이 납니다.
- 주리의 헬리콥터를 켜 후 즉시 수평면에 올려놓으십시오. 지로시스템이 자동으로 정렬 작동합니다.
- 왼쪽 조이스틱, 즉 속도조절 공기를 뿜쪽으로 완전히 밀어올린 다음, 다시 아랫쪽으로 0 위치까지 내리십시오.
- 헬리콥터가 시스템을 정확히 초기화하고 작동 준비가 될 때까지 잠시 기다리십시오. 접속이 성공적으로 이루어졌습니다.
- 컨트롤러의 LED가 지속적으로 빛을 발합니다.

비행 준비 점검표

이 점검표는 사용설명서 내용을 대체하지 않습니다. 이 점검표를 펙 스타트 가이드로 사용하지 수 있으며 불투명하고, 계속 진행하기 전에 우선 이 조작설명서를 완전히 숙독하실 것을 적극 권장합니다.

- 포장내용물을 점검하십시오
- 충전기를 전원에 연결하십시오
- 리튬 이온 종합체 전지를 "리튬 이온 종합체 전지 충전하기" 항목에 설명된대로 충전하십시오
- AA 건전지 2개를 컨트롤러에 장착하시되, 양극이 제대로 맞는지 주의하십시오.
- 비행하기에 적당한 주변을 찾으십시오
- 아래 4에 묘사된대로 접속을 시도하십시오
- 헬리콥터 여러 대를 동시에 비행하려면 위에 설명한 항목을 반복하십시오.
- 조종이 되는지 점검하십시오
- 조종 방법을 익히십시오
- 필요한 경우 "헬리콥터 조종하기" 항목에 설명된대로 헬리콥터를 트리밍하여 헬리콥터가 부유비행시 조종하지 않은 상태로 제 위치에서 벗어나지 않게 하십시오. 15 16
- 헬리콥터를 출발하려면 단추 7을 누르십시오. (사진 5)
- 헬리콥터는 이제 비행 준비가 되었습니다.
- 헬리콥터가 어떤 기능도 보이지 않으면 위에 언급한 접속 절차를 다시 시도하십시오.
- 모델을 비행시키십시오
- 모델을 착륙시키십시오
- 모델을 끄십시오
- 원격조종기를 항상 마지막으로 끄십시오

컨트롤러의 기능

1. 파워 스위치 (ON/OFF)
2. 점검 점등
3. 속력
4. 전진/후진 후미(원형 회전)
5. 후미 트리머
6. Auto Landing" 단추
7. Auto Start & Fly to 1m" 단추
8. 전지탑

헬리콥터 설명

1. 동축회전장치
2. 후미
3. 리튬 이온 종합체 전지를 충전 하기 위한 충전 펙
4. 착륙 셀배
5. ON/OFF 스위치

헬리콥터 조종

7 카레라 RC 헬리콥터의 조종기능을 아직 모르시면, 첫 비행전에 몇 분간 시간을 내어 그 기능을 익히십시오. 좌측, 혹은 우측으로 설명된 것은 조종실의 시카에서 바라본 것입니다(조종사 시각). 속도조절공기를 위로 눌러 주회전날개의 회전속도를 늦추십시오. 회전속도를 늦추면 모델이 상승하기 시작합니다. 속도조절공기의 기울임을 감소하여 주회전날개의 회전속도를 줄이면 헬리콥터가 강하합니다. 모델이 지상에서 떠오르면, 속도조절공기를 조심스럽게 움직여서 모델을 뿜쪽으로 아랫쪽으로 조절할 수 있고, 갑자기 상승하거나 강하하지 않는 정체 부유비행을 할 수 있습니다. 왼쪽 조이스틱을 사용하여 앞으로 오른쪽 조이스틱으로 동일한 비행고도에서 전진, 후진과 원형비행을 할 수 있습니다.

8 오른쪽 공기(후미)를 왼쪽으로 움직이면, 헬리콥터의 앞부분이 주회전축을 중심으로 왼쪽으로 원형 회전을 합니다. 오른쪽 공기(후미)를 오른쪽으로 움직이면, 헬리콥터의 앞부분이 주회전축을 중심으로 오른쪽으로 원형 회전을 합니다. 헬리콥터가 부유 비행 상태로 확실한 중립 비행 상태에 도달할 때까지, 오른쪽 공기(후미)를 움직이지 않은 채로, 후미 균형장치를 작동하십시오.

9 전진/후진 공기는 헬리콥터가 앞쪽/뿜쪽으로 기울는 것을 조종합니다. 이 공기를 앞쪽으로 누르면, 헬리콥터의 전면이 아랫쪽으로 움직이고 헬리콥터는 전진 비행을 합니다. 전진/후진 공기를 뿜쪽으로 누르면, 헬리콥터는 뿜쪽으로 움직이고 후진 비행을 합니다.

비행 장소 선택

10 헬리콥터는 바람이 불지 않거나 매우 약한 바람에서만 실의 비행을 할 수 있습니다. 땅 표면 가까이 바람이 없어도 표면으로부터 약간의 간격만 생기면 매우 바람이 거셀 수 있다는 것을 주의하십시오. 이 점을 주의하지 않으면 헬리콥터가 완전 손상을 입을 수 있습니다.

11 헬리콥터 트리밍을 완료하였고 조종과 비행능력에 익숙해진 다음에는 더 적은 공간과 완전히 비어있지 않은 주변에서 비행을 감행해도 됩니다.

자동 고도 조절 기능

12 비행 중 왼쪽 조이스틱에서 손을 놓으면 헬리콥터는 자동으로 현 고도를 유지합니다. 왼쪽 조이스틱을 사용하지 않고 오른쪽 조이스틱으로 동일한 비행고도에서 전진, 후진과 원형비행을 할 수 있습니다.

Auto-Start & Fly to =1 m

13 컨트롤러의 "Auto Start & Fly to 1 m" 단추를 눌러 모터가 시동하고 자동으로 약 1 미터 고도에 오르길 할 수 있습니다. 이륙이 시행되는 과정에서 언제든지 오른쪽 조이스틱을 눌러 비행 방향을 바꿀 수 있습니다. 약 1 미터 고도에 도달하면 헬리콥터는 자동으로 고도를 유지합니다.

Auto Landing

14 "Auto Landing" 단추를 눌러 언제든지 자동 착륙 기능을 실행할 수 있습니다. 이 때 날개의 회전 속도가 서서히 감소합니다. 이륙이 실행되는 과정에서 언제든지 오른쪽 조이스틱을 움직여 착륙 위치를 바꿀 수 있습니다. 헬리콥터가 지면에 다다르면 모터가 꺼집니다.

헬리콥터 트리밍하기

1. 자동 트리밍
1. 헬리콥터를 수평면에 올려 놓으십시오.
2. "모델을 컨트롤러에 접속하기"에 설명된 대로 헬리콥터를 컨트롤러에 접속하십시오
3. 속도조절 공기와 전진/후진 공기를 동시에 오른쪽 아래 묘사리까지 미십시오. 헬리콥터의 LED가 짧게 깜박이고 난 후 지속적으로 빛을 발합니다. 신호음이 1번 울립니다.
4. 중립 위치 설정이 완료되었습니다.

16 헬리콥터가 부유비행 상태에서 원형 비행 공기를 움직이지 않았음에도 불구하고 제 자리에서 왼쪽, 혹은 오른쪽으로 회전하면 다음과 같이 진행하십시오: 헬리콥터가 저절로 빠르거나 천천히 제 축을 중심으로 왼쪽으로 회전하면, 원형 비행을 위한 왼쪽 아래 트리밍 단추를 단계적으로 오른쪽으로 누르십시오. 헬리콥터가 오른쪽으로 회전하면, 원형 비행을 위한 트리밍 단추를 단계적으로 왼쪽으로 누르십시오.

문제 해결

- 문제: 컨트롤러가 작동하지 않음.
원인: ON/OFF 파워 스위치가 „OFF“로 되어 있음.
해결책: ON/OFF 파워 스위치를 „ON“으로 전환.
원인: 전지가 잘못 장착됨.
해결책: 전지가 제대로 장착되었는지 검토하십시오.
원인: 전지가 충분하지 않음.
해결책: 새 전지를 장착하십시오.
- 문제: 헬리콥터를 컨트롤러로 조종할 수 없음.
원인: 컨트롤러의 파워 스위치가 „OFF“로 되어 있음.
해결책: 먼저 컨트롤러의 파워 스위치를 „ON“으로 전환.
원인: 컨트롤러가 간혹 헬리콥터의 수신기와 제대로 연결되어 있지 않을 수 있습니다.
해결책: 아래 4에 묘사된대로 접속을 시도하십시오.
- 문제: 회전날개가 움직이지 않음.
원인: 모델 및 컨트롤러의 전원 스위치가 "OFF"입니다.
해결책: On/OFF 파워 스위치를 켜십시오.
원인: 전지가 너무 약하거나 비어 있음.
해결책: 전지 충전(전지 충전"에 관한 설명 참고).
- 문제: 헬리콥터가 뜨지 않음.
원인: 회전 날개가 너무 서서히 움직임.
해결책: 속력 공기를 위로 당기십시오.
원인: 전지 성능이 충분하지 않음.
해결책: 전지 충전(전지 충전"에 관한 설명 참고).
- 문제: 헬리콥터가 비행중 뚜렷한 이유없이 속력을 잃고 강하함.
원인: 전지가 너무 약함.
해결책: 전지 충전(전지 충전"에 관한 설명 참고).
- 문제: 헬리콥터가 너무 빨리 착륙함.
원인: 속도공기를 통해 조종이 되지 않음.
해결책: 속도공기를 천천히 당길 것.
원인: 속도공기를 너무 빨리 당김.

오류와 변동이 있을 수 있습니다. • 색깔과 최종 디자인에 변동이 있을 수 있습니다. 기술과 디자인상의 변동이 있을 수 있습니다. • 펙트그램 = 상징그림

