


**1**

**3,7V — 150mAh  
0,56Wh LiPo**



**2x 1.5 V Mignon AA batteries  
2x Piles 1, 5 V mignon AA  
2x Pilas de 1,5 V Mignon AA**

\* Nur ein Modell enthalten - Contains only one model - contient un seul modèle - Contiene sólo un modelo - Contiene un solo modellino - Bevat slechts één model  
 Contém só uma miniatura - Endast en modell - Sisältää vain yhden radio-ohjattavan - Zawiera tylko jeden model - Csak egy modellt tartalmaz - Vključen samo en model  
 Obsahuje pouze jeden model - Obsahuje len jeden model - Inneholder kun samme modell - Inneholder kun én model - لا يحتوي إلا على نموذج واحد فقط - Περιέχει μόνο ένα μοντέλο - 含一个模型 - 모델 한 개만 들어있음






**2**

**LED OFF = Charging  
DEL OFF = En charge  
LED OFF = Cargando**

**Green = Ready  
Vert = Prêt  
Verde = Listo**

**3**

**2x 1.5 V Mignon AA batteries  
2x Piles 1, 5 V mignon AA  
2x Pilas de 1,5 V Mignon AA**

**4****5**

**(D)** 30% = Einsteiger Modus - 60% = Medium Modus  
100% = Advanced Modus -> 3D Modus

**(GB USA)** 30% = beginner mode - 60% = medium mode  
100% = Advanced Modus -> 3D Modus

**(F)** 30% = mode débutant  
60% = mode moyen  
100% = mode avancé -> mode 3D

**(E)** 30% = modo principiante  
60% = modo medio  
100% = modo avanzado -> modo 3D

