



1

370501032
370501038



370501033
370501038



370501035



370501036




2x 1.5 V Micro AAA batteries
2x Piles 1, 5 V micro AAA
2x Pilas de 1,5 V Micro AAA



370501032 - # 370501033 - # 370501035 - # 370501036:

Nur ein Modell enthalten - Contains only one model - contient un seul modèle - Contiene sólo un modelo - Contiene un solo modellino - Bevat slechts één model
Contém só uma miniatura - Endast en modell - Sisältää vain yhden radio-ohjattavan - Zawiera tylko jeden model - Csak egy modellt tartalmaz - Vključen samo en model
Obsahuje pouze jeden model - Obsahuje len jeden model - Inneholder kun samme model - Inneholder kun én model - لا يحتوي إلا على نموذج واحد فقط - Περιέχεται μόνο ένα μοντέλο - 含一个模型 - 모델 한 개만 들어있음

TM & © 2020 Nintendo. All Rights Reserved. - TM et © 2020 Nintendo. Tous droits réservés.

2

OFF

LED OFF = Charging
DEL OFF = En charge
LED OFF = Cargando

Green = Ready
Vert = Prêt
Verde = Listo

3

2x 1.5 V Micro AAA batteries
2x Piles 1, 5 V micro AAA
2x Pilas de 1,5 V Micro AAA

