


**1**

# 370501032  
# 370501038



# 370501033  
# 370501038



# 370501035



# 370501036




2x 1.5 V Micro AAA batteries  
2x Piles 1, 5 V micro AAA  
2x Pilas de 1,5 V Micro AAA



# 370501032 - # 370501033 - # 370501035 - # 370501036:

Nur ein Modell enthalten · Contains only one model · contient un seul modèle · contiene sólo un modelo · Contiene un solo modellino · Bevat slechts één model · Contém só uma miniatura · Endast en modell · Sisältää vain yhden radio-ohjattavan · Zawiera tylko jeden model · Csak egy modellt tartalmaz · Vključen samo en model · Obsahuje pouze jeden model · Obsahuje len jeden model · Inneholder kun samme model · Inneholder kun én model · لا يحتوي إلا على نموذج واحد فقط · Περιέχεται μόνο ένα μοντέλο · 含一个模型 · 모델 한 개만 들어있음

TM & © 2020 Nintendo. All Rights Reserved. · TM et © 2020 Nintendo. Tous droits réservés.

**2**

LED OFF = Charging  
DEL OFF = En charge  
LED OFF = Cargando

Green = Ready  
Vert = Prêt  
Verde = Listo

**3**

2x 1.5 V Micro AAA batteries  
2x Piles 1, 5 V micro AAA  
2x Pilas de 1,5 V Micro AAA

