



**1**

# 370501032  
# 370501038



# 370501033  
# 370501038



# 370501035



# 370501036




2x 1.5 V Micro AAA batteries  
2x Piles 1, 5 V micro AAA  
2x Pilas de 1,5 V Micro AAA



# 370501032 - # 370501033 - # 370501035 - # 370501036:

Nur ein Modell enthalten - Contains only one model - contient un seul modèle - Contiene sólo un modelo - Contiene un solo modellino - Bevat slechts één model  
Contém só uma miniatura - Endast en modell - Sisältää vain yhden radio-ohjattavan - Zawiera tylko jeden model - Csak egy modellt tartalmaz - Vključen samo en model  
Obsahuje pouze jeden model - Obsahuje len jeden model - Inneholder kun samme model - Inneholder kun én model - لا يحتوي إلا على نموذج واحد فقط - Περιέχεται μόνο ένα μοντέλο - 含一个模型 - 모델 한 개만 들어있음

TM & © 2020 Nintendo. All Rights Reserved. - TM et © 2020 Nintendo. Tous droits réservés.

**2**

LED OFF = Charging  
DEL OFF = En charge  
LED OFF = Cargando

Green = Ready  
Vert = Prêt  
Verde = Listo

**3**

2x 1.5 V Micro AAA batteries  
2x Piles 1, 5 V micro AAA  
2x Pilas de 1,5 V Micro AAA

